



XTRFY M4 QUICK START GUIDE



CPI

- 400
- 800
- 1200
- 1600
- 3200
- 4000
- 7200
- 12000



POLLING RATE

125 Hz 500Hz 1000Hz




125Hz 500Hz 1000Hz




**RGB
EFFECTS**







+





BRIGHTNESS



+





 FOR MORE INFORMATION, DOWNLOAD THE MANUAL AT XTRFY.COM

 FÖR MER INFORMATION, LADDA NER DEN FULLSTÄNDIGA MANUALEN PÅ XTRFY.COM

 FOR MER INFORMASJON LAST NED BRUKSANVISNINGEN PÅ XTRFY.COM

 FOR MERE INFORMATION, DOWNLOAD VORES FULDE MANUAL PÅ XTRFY.COM

 LISÄTIETOJA SAAT LATAAMALLA KOKO KÄYTTÖOHJEEN XTRFY.COM-VERKKOSIVUSTOLLA.

 FÜR WEITERE INFORMATIONEN, LADEN SIE DAS VOLLSTÄNDIGE HANDBUCH BEI XTRFY.COM

 POUR PLUS D'INFORMATIONS, TÉLÉCHARGEZ LE MANUEL COMPLET SUR XTRFY.COM

 SI DESEAS OBTENER MÁS INFORMACIÓN, DESCARGA EL MANUAL COMPLETO DESDE XTRFY.COM

 PARA MAIS INFORMAÇÕES, TRANSFIRA O MANUAL COMPLETO EM XTRFY.COM

 PER ULTERIORI INFORMAZIONI, SCARICA IL MANUALE COMPLETO SU XTRFY.COM

 DETAYLI BİLGİ İÇİN LÜTFEN XTRFY.COM'DAN KULLANIM KILAVUZUNU İNDİRİN.

 WIĘCEJ INFORMACJI ZNAJDZIESZ W INSTRUKCJI OBSŁUGI, DOSTĘPNEJ NA XTRFY.COM

 PRO VÍCE INFORMACÍ SI STÁHNĚTE KOMPLETNÍ MANUÁL NA XTRFY.COM

 ДЛЯ ПОЛУЧЕНИЯ ДОПОЛНИТЕЛЬНОЙ ИНФОРМАЦИИ ЗАГРУЗИТЕ ПОЛНОЕ РУКОВОДСТВО НА XTRFY.COM

 자세한 정보는 XTRFY.COM에서 전체 매뉴얼을 다운로드 하거나.

 想要得到更多信息, 请在WWW.XTRFY.COM网站上下载说明书.

 設定や他の情報の詳細は、xtrfy.jpから取扱説明書をダウンロードしてください。

